





KNOW YOUR PRODUCT




WHAT'S IN THE BOX

1. Headset
2. USB-A receiver
3. USB-C to A adapter
4. USB-A to C charging cable
5. Travel bag
6. User documentation




POWER ON/OFF

1. Press power button for 1 second.
2. Once powered on, light indicator turns white.
If no device is connected, it will flash white slowly.




PAIRING VIA BLUETOOTH®

1. Press power button for 2 seconds. Light indicator will flash white rapidly.
2. Open *Bluetooth*® settings on your device.
3. Select Zone Wireless in discoverable devices.
4. Once successfully paired, light indicator will turn solid white.




PAIRING VIA USB RECEIVER

1. **USB-A**
Insert the receiver into the computer USB-A port.
USB-C
Insert the USB-A receiver into the USB-C adapter.
Then insert the adapter into the computer USB-C port.
2. Headset is already paired to the receiver it ships with. Just power on the headset. Once successfully paired, the light indicator on the receiver will remain solid white. Light indicator on the headset will turn solid white.




ADJUSTING HEADSET

1. Adjust headset by sliding earcups up and down the headband.
2. It may be easier to adjust the headset on your head. Move the earcups up and down the headband until they sit comfortably on your ears.




ADJUSTING THE MICROPHONE BOOM

1. Microphone boom rotates 270 degrees. Wear it on either left or right side. Audio channel will switch automatically, depending on the direction you are wearing the microphone.
2. Flexible microphone boom — adjust boom location to capture voice better.




HEADSET CONTROLS

TEAMS version			
	Usage	Button	Action
Call controls	Answer / End call	Multi-function	Short press
	Reject call		2 second press
	Resume call		Short press
	Transfer active call to other device		Short press
Teams activities	Check connection to teams		Short press
	Quick access to Teams		Short press
	Respond to Teams notifications		Short press
	Trigger Teams voice skills (Cortana)		2 second press
Media controls	Play / Pause	Multi-function	Double press
	Track forward	Multi-function and "+"	Short press
	Track backward	Multi-function and "-"	Short press
Volume	Volume up	"+"	Short press
	Volume down	"-"	Short press
Headset connection and battery status	Check connectivity and battery life	"+" and "-"	Short press



MSFT Teams version

UC version			
	Usage	Button	Action
Call controls	Answer / End call	Multi-function	Short press
	Reject call		2 second press
Voice assistant		Multi-function	2 second press
Media controls	Play / Pause	Multi-function	Double press
	Track forward	Multi-function and "+"	Short press
	Track backward	Multi-function and "-"	Short press
Volume	Volume up	"+"	Short press
	Volume down	"-"	Short press
Headset status	Check connectivity and battery life	"+" and "-"	Short press




UC version

Note:

- Teams activities are only functional when Teams is running on an unlocked computer.
- Media control functionality depends on type of application.
- Call activities are always the first priority. When two devices are connected, the *Bluetooth®* connection will be prioritized over receiver. When two *Bluetooth®* devices are connected, the last active device will override the other.


Tip: Button customizations and Music EQ controls available on Logi Tune app.

MUTE




Mute

Move mic boom up to mute



Move mic boom down to unmute

Voice notifications indicate when the microphone is on/off mute




"Mute on"
"Mute off"

ACTIVE NOISE CANCELLATION (ANC)

ANC blocks out the noise around you to help you concentrate on the task at hand.


1. Press the ANC button on the side of the earcup.
2. There will be voice notifications when turning ANC on and off. These can be turned off in the Logi Tune app.



"ANC on"
"ANC off"


HEADSET LIGHT INDICATOR

Light		Status
White	Solid	Powered on or fully charged
	Breathing	Battery charging
	Fast pulsing	Bluetooth® pairing mode
	Slow pulsing	No paired device
Red	Solid	Low battery
	Fast pulsing	Bluetooth® pairing mode while low battery
	Slow pulsing	No paired device while low battery




RECEIVER INDICATOR LIGHT

TEAMS version		
Light		Status
White	Fast flashing	Pairing mode
	Solid	Paired
	Repeat flashing on and off	Incoming call
Purple	Pulsing	Connecting to Teams/ Teams notifications
	Flashing for 10 seconds and off	Failed connection to Teams
	Flashing 3 times and off	Not connected to Teams
	Solid	Connected to Teams
Red	Solid	Mute on



UC version		
Light		Status
White	Fast flashing	Pairing mode
	Solid	Paired
	Repeat flashing on and off	Incoming call
Red	Solid	Mute on




CHARGING

*Headset automatically powers off when left idle.
Sleep timer can be changed in the Logi Tune App.*

Headset indicator light will turn RED when battery is low.

Charging via USB cable


1. Plug the USB-C cable end into the USB-C port on the bottom of the earcup.
2. Plug the USB-A end into the USB-A charging port on your computer or AC adapter.
3. Indicator light will be a breathing white light for charging.
4. Indicator light will be solid white when fully charged.
 - 2 hours will fully charge the battery.
 - 5 minutes will give you 1 hour of talk time.
5. Headset can be used with receiver and *Bluetooth®* paired while charging.



Charging via Qi wireless charger

1. Fold headset with the wireless charging icon on the earcup to the outside.
2. Place earcup with wireless charging icon on top of any Qi wireless charging base.*
3. Indicator light will be a breathing, white light when charging.
4. Indicator light will be solid white when fully charged.
 - 2 hours of charging fully charges the battery.

* Qi wireless charging base is not included.



LOGI TUNE APP

1. Download Logi Tune Desktop from www.logitech.com/tune
2. Download the Logi Tune mobile app from the Apple App Store® or Google Play™ stores by searching for "Logi Tune".



ADJUSTING SIDETONE

Sidetone lets you hear your own voice during conversations so you are aware of how loud you are talking. In the Logi Tune App, select the sidetone feature, and adjust the dial accordingly.

- A higher number means you hear more external sound.
- A lower number means you hear less external sound.

AUTO SLEEP TIMER

By default, your headset will automatically power off when not in use for one hour. Adjust the sleep timer in the Logi Tune App.

UPDATE YOUR HEADSET

It is recommended to update both your headset and receiver. To do so, download the Logi Tune Desktop from www.logitech.com/tune

RESET YOUR HEADSET

To reset your headset back to its original state, power headset on, press and hold the ANC button and volume '-' button for 5 seconds. The headset is successfully reset when it powers off and indicator light turns off.

DIMENSIONS

HEADSET:

Height x Width x Depth:
174.7 x 176.7 x 70.7 mm

WEIGHT:

0.1808Kg

EARPADS:

Height x Width x Depth:
70.7 x 70.7 x 16.4 mm

RECEIVER:

Height x Width x Depth:
21.5 x 13.6 x 6.0 mm

ADAPTER:

Height x Width x Depth:
25.2 x 16.5 x 9.5 mm